

**PETRONAS**

**Arbor<sup>®</sup>**



The full range of ARBOR Lubricants is available on request.  
Please ask your sales manager.



+49 - 49 03 - 91 56 00



sales@otv-international.de



www.otv-international.de

### ARBOR Power

10301609	Arbor Power Mix	1 Liter
10321100	Arbor Power Cut	200 Liter
10325019	Arbor Power Cut	5 Liter
10321609	Arbor Power Cut	1 Liter
10315019	Arbor Power Cut BIO	5 Liter
10285019	Arbor Power	5 Liter
10281609	Arbor Power	1 Liter

### ARBOR Alfaprime

36371100	Arbor Alfaprime 15W-40	200 Liter
36371910	Arbor Alfaprime 15W-40	20 Liter
36362000	Arbor Alfaprime 10W-30 Tankware	
36361100	Arbor Alfaprime 10W-30	200 Liter
36361910	Arbor Alfaprime 10W-30	20 Liter

### ARBOR Alfatech

36401100	Arbor Alfatech Synth 10W-40	200 Liter
36401910	Arbor Alfatech Synth 10W-40	20 Liter
36405019	Arbor Alfatech Synth 10W-40	5 Liter
10242123	Arbor Alfatech 15W-40 IBC	1000 Liter
10241100	Arbor Alfatech 15W-40	200 Liter
10241310	Arbor Alfatech 15W-40	60 Liter
10241910	Arbor Alfatech 15W-40	20 Liter
10245019	Arbor Alfatech 15W-40	5 Liter
36541100	Arbor ALFATECH 10W-30	200 Liter
36541910	Arbor ALFATECH 10W-30	20 Liter

### ARBOR Super

36411100	Arbor Super 15W-40	200 Liter
36411310	Arbor Super 15W-40	60 Liter
36411910	Arbor Super 15W-40	20 Liter
36415019	Arbor Super 15W-40	5 Liter
36421100	Arbor Super 20W-50	200 Liter

36421910	Arbor Super 20W-50	20 Liter
36425019	Arbor Super 20W-50	5 Liter
36431100	Arbor Super 40	200 Liter
36431910	Arbor Super 40	20 Liter
36731100	Arbor Super 10	200 Liter
36731910	Arbor Super 10	20 Liter

### ARBOR Universal

36381100	Arbor Universal 10W-40	200 Liter
36381910	Arbor Universal 10W-40	20 Liter
36441100	Arbor Universal 15W-40	200 Liter
36441910	Arbor Universal 15W-40	20 Liter
36445019	Arbor Universal 15W-40	5 Liter

### ARBOR MTF

36451100	Arbor MTF SPECIAL	200 Liter
36451910	Arbor MTF SPECIAL	20 Liter
36572000	Arbor MTF Tankware	
36572121	Arbor MTF IBC	1000 Liter
36572123	Arbor MTF IBC	1000 Liter
36571100	Arbor MTF	200 Liter
36571310	Arbor MTF	60 Liter
36571910	Arbor MTF	20 Liter
36575019	Arbor MTF	5 Liter
36671910	Arbor MTF Special UP	20 Liter

### ARBOR Multi

36461100	Arbor Multi FX	200 Liter
36461910	Arbor Multi FX	20 Liter
36465019	Arbor Multi FX	5 Liter

### ARBOR MTA

36491615	Arbor MTA	1 Liter
----------	-----------	---------

### ARBOR TRW

36502123	Arbor TRW 90 IBC	1000 Liter
36501100	Arbor TRW 90	200 Liter

36501910	Arbor TRW 90	20 Liter
36505019	Arbor TRW 90	5 Liter
36511910	Arbor TRW 90 LS	20 Liter
36511609	Arbor TRW 90 LS	1 Liter
36581100	Arbor TRW 140	200 Liter
36581910	Arbor TRW 140	20 Liter
36585019	Arbor TRW 140	5 Liter

### ARBOR TTF

36561100	Arbor TTF	200 Liter
36561910	Arbor TTF	20 Liter

### ARBOR Hydraulic

36711100	Arbor Hydraulic 46	200 Liter
36711910	Arbor Hydraulic 46	20 Liter
36472123	Arbor Hydraulic 46 HV IBC	1000 Liter
36471100	Arbor Hydraulic 46 HV	200 Liter
36471910	Arbor Hydraulic 46 HV	20 Liter
36481100	Arbor Hydraulic 68	200 Liter
36481910	Arbor Hydraulic 68	20 Liter
36601910	Arbor Hydraulic 46 BIO-V	20 Liter

### ARBOR BF-LHM

36631619	Arbor BF-LHM	1 Liter
----------	--------------	---------

### ARBOR HTC

36551100	Arbor HTC 46	200 Liter
36551910	Arbor HTC 46	20 Liter

### ARBOR Freeze

36531100	Arbor Freeze -38 °C Ready	200 Liter
36531910	Arbor Freeze -38 °C Ready	20 Liter
36535019	Arbor Freeze -38 °C Ready	5 Liter
36621100	Arbor Protective Fluid	200 Liter
36621910	Arbor Protective Fluid	20 Liter
36625019	Arbor Protective Fluid	5 Liter